



LITEMAX SLD1745

Sunlight Readable 17" LCD Display

(1st Edition 8/4/2008)

All information is subject to change without notice.

| Approved by | Checked by | Prepared by |
|-------------|------------|-------------|
| David | Ming | Jack |

LITEMAX Electronics Inc.
8F-2, No.133, Lane 235, Bau-chiau Rd.,
Shin-dian City, Taipei County, Taiwan R.O.C.
Tel : 886-2-8919-1858
Fax: 886-2-8919-1300
Homepage: <http://www.litemax.com.tw>

Record of Revision

| Version and Date | Page | Old Description | New Description | Remark |
|------------------|------|-----------------|-----------------|--------|
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Content

| | |
|--------------------------------------|----|
| Record of Revision..... | 2 |
| Content | 3 |
| Introduction | 4 |
| Hardware Installation | 4 |
| The Display Timing..... | 6 |
| The Display Outline Dimensions | 7 |
| The Display Controls..... | 8 |
| The Screen Adjustment..... | 9 |
| Quick Installation..... | 9 |
| Troubleshooting Tips..... | 10 |
| LCD Specification..... | 11 |
| Product Safety Precautions..... | 12 |

Introduction

Welcome to enjoy the fantastic sightseeing world. This new technology will bring you the whole new feeling about the “monitor”. We show here some of the major advantages of the LCD monitor. You will really find some other advantages when you use it.

Hardware Installation

This chapter will guide you the correct installation procedures of your LCD monitor.

Unpacking

After you unpack your LCD Monitor, please make sure that the following items are included in the carton and in good condition. If you find that any of these items are damaged or missing, please contact your dealer immediately.


- One LCD Monitor
- 15-pin D-sub Video cable (Option)
- AC/DC adapter with 12V DC output (Option)
- AC power cord (Option)
- Quick installation Guide

Installation

This analog LCD display **does not** require any special drivers. Necessary drivers are supplied by the video card manufacturer and may be found on the diskettes supplied with the video card that came with your computer. Windows 98/2000/XP drivers for both the display and the video card are supplied on the Windows 98/2000/XP CD or diskettes. Unfortunately, Microsoft did not provide a complete listing of the displays on the initial retail release. You may use the SXGA 1280x1024 as the display type. The video card must also be set up correctly in Windows 98/2000/XP and make sure the video output of the VGA card is on list in Section 6.1 or check your Video Card manual or Windows 98/2000/XP Read me file for further information on Video Card. After the question listed above is solved, we continue the setup procedure as below.


1. Turn power off both Computer and Display before making any connection.
2. Install Display on the solid horizontal surface such as a table or desk.
3. Connect the power cable and the AC/DC adapter, then connect adapter toe the back of the LCD monitor.
4. The LCD monitor comes with a 15-pin video cable; you may use this cable for both IBM PC's & compatibles and Macintosh.
5. Tighten the screws of the Display cable until the connectors are fastened securely.
6. Switch on power to the Computer system, then to the monitor.

The following picture provides the connection outline



Video Input Pin Assignment

This section describes the pin assignment of the LCD's video connector. It is called 15pin Mini D-sub connector.



| Pin No. | Signal Connector |
|---------|-------------------------------|
| 1 | Red Video Signal |
| 2 | Green Video Signal |
| 3 | Blue Video Signal |
| 4 | N.C. |
| 5 | Ground |
| 6 | Ground for red video signal |
| 7 | Ground for green video signal |
| 8 | Ground for blue video signal |
| 9 | N.C. |
| 10 | Ground |
| 11 | N.C. |
| 12 | DDC data |
| 13 | Horizontal sync signal |
| 14 | Vertical sync signal |
| 15 | DDC clock |


The Display Timing

The following table displays optimum quality modes that the LCD monitor provides. If the other video modes are used, the monitor will stop working or display a poor quality picture.

| TIMMING | |
|---------|------------------------------------|
| MODE | RESOLUTION |
| VGA | 640x480@60Hz |
| | 640x480@72Hz |
| | 640x480@75Hz |
| SVGA | 800x600@56Hz |
| | 800x600@60Hz |
| | 800x600@72Hz |
| | 800x600@75Hz |
| XGA | 1024x768@60Hz |
| | 1024x768@70Hz |
| | 1024x768@75Hz |
| SXGA | 1280x1024@60Hz |
| | 1280x1024@70Hz |
| | 1280x1024@75Hz |
| WXGA | 1366x768@60Hz |
| WSXGA+ | 1680x1050@60Hz |
| SXGA+ | 1400x1050@60Hz(Pixel f 101.000MHz) |
| | 1400x1050@60Hz(Pixel f 121.750MHz) |
| | 1400x1050@75Hz |
| UXGA | 1600x1200@60Hz |
| | 1600x1200@65Hz |
| | 1600x1200@75Hz |

The Display Controls

Membrane Control Button



❶ **POWER SWITCH:** Pushing the power switch will turn the monitor on. Pushing it again to turn the monitor off.

❷ **Power LED:** Power ON-Green / Power off-No.

❸ **Up Key >:** Increase item number or value of the selected item.

❹ **Menu Key:** Enter to the OSD adjustment menu. It also used for go back to previous menu for sub-menu, and the change data don't save to memory.

❺ **Down Key <:** Decrease item number or item value when OSD is on. When OSD is off, it is hot key for input switch between VGA, AV, and S-video.

Screen Adjustment Operation Procedure

- 1. Entering the screen adjustment**
The setting switches are normally at stand-by. Push the **Menu Key** once to display the main menu of the screen adjustment. The adjustable items will be displayed in the main menu.
- 2. Entering the settings**
Use the **Down Key <** and **Up Key >** buttons to select the desired setting icon and push the SELECT button to enter sub-menu.
- 3. Change the settings**
After the sub-menu appears, use the **Down Key <** and **Up Key >** buttons to change the setting values.
- 4. Save**
After finishing the adjustment, push the SELECT button to memorize the setting.
- 5. Return & Exit the main menu**
Exit the screen adjustment; push the "MENU" button. When no operation is done around 30 sec (default OSD timeout), it goes back to the stand-by mode and no more switching is accepted except MENU to restart the setting.

The Screen Adjustment

Main Menu

You can adjust the brightness, contrast, display colors, the horizontal and vertical position of the display and OSD menu, etc. through the main menu display.



OSD picture

(may vary on different AD board.)

The **Down Key** < and **Up Key** > are used to scroll through items within the menu. The selected item is highlighted as the scrolling move along. The SELECT key is used to activate the highlighted item. During this state, MENU key is used to close the OSD menu from the screen.

Quick Installation

Please follow the following descriptions step by step. (The 7 diagrams can be your references):



Step 1 Plug a terminal of the VGA cable to the signal connector at the rear of the Monitor.

Step 2 Plug the other terminal of the VGA cable to the signal connector at the rear of PC.

Step 3 Plug Adapter output to the jack at the rear of LCD Monitor.

Step 4 Plug the Power cord to the Adapter.

Step 5 Connect the Power cord to the power outlet.

Step 6 Turn on the LCD Monitor and PC.

Step 7 You can also plug in RCA jack to connect your video source like DVD or VCR.

You can view video over PC by pressing "PIP" button on remote controller.

Troubleshooting Tips

In the event that you experience trouble with your Display, check the following items before contacting the dealer from whom the Display was purchased. The most common problems usually involve an incorrectly an incorrect connection from the Video Card to the Display. We recommend that you also consult your Video Card User's manual during the Troubleshooting Procedure. Do not exceed the maximum refresh rate recommended for the display.

| Problem | Troubleshooting Tip |
|--|--|
| No image on display screen | <ol style="list-style-type: none"> 1. Check that power cord of the Computer has been connected securely into wall outlet or grounded extension cable or strip. 2. Check that power switch of the Display has been pressed and LED on the front of Display is lit. 3. Check that Video (Signal) cable from the Display has been securely and correctly connected. 4. Check that Video Card is firmly seated in card slot of Computer motherboard. 5. Check that the video input from the Video Card falls within the timing range. |
| Abnormal image | <ol style="list-style-type: none"> 1. Check that the video input from the Video Card falls within the timing range. 2. Check that Video (Signal) Cable from the Display has been securely and correctly connected to the Video Connector at the rear side of the Computer. |
| Colors of image on screen are abnormal | <ol style="list-style-type: none"> 1. Check that Video (Signal) Cable from the displays has been securely and correctly connected to the 15-pin Video Connector at the rear side of the computer. |
| Disturbances on Screen | <ol style="list-style-type: none"> 1. OSD adjustment is incorrect. Please consult section for OSD screen adjustment procedures. |

※Please contact your local authorized distributors /retailers if you run into other unsolved problems.

LCD Specification

| | |
|--------------------|---|
| Model No. | SLD1745 |
| LCD Display | 17" TFT LCD Module |
| Display Area | 337.92 (H) x 270.336 (V) mm |
| Original Panel No. | AUO M170EG01VD |
| Display Surface | Non-glare hard coated |
| Luminance | 1000 cd/m ² |
| Resolution | 1280 x 1024 (SXGA) |
| Contrast Ratio | 800:1 |
| Display Colors | 16.2M colors |
| Pixel Arrangement | RGB (Red, Green, Blue) vertical stripe |
| Pixel Pitch | 0.264 (H) x 0.264(V) mm |
| Viewing Angle | At the contrast ratio 10:1 : Horizontal: Left side 80° (typ.), Right side 80° (typ.) : Vertical: Up side 80° (typ.), Down side 80° (typ.) |
| Color Gamut | At LCD panel center 60% (typ.) [against NTSC color space] Ton (black 10%→white 90%) |
| Response Time | 5ms (Typ.) |
| Sync | LVDS x1 Channel |
| Signal Connector | 15 Pin D-sub, 29 Pin DVI |
| F/R Control Button | Power Switch, Menu, Select (+,-) |
| OSD Menu | Brightness, Contrast, H/V Position, Color, Phase, Clock, Language, Management |
| Power Consumption | At maximum luminance and checkered flag pattern 50W (Max) |
| Module Size | 436(H) x373 (V) x61.6 (D) mm |
| Weight (Net) | 5.77kg |
| Option | Touch (Resistive/ Capacitive) |

※ Specifications subject to change without notice.

Product Safety Precautions

Follow all warnings and instructions marked on the product.

Do not use this product near water.

This display should be installed on a solid horizontal base.

When cleaning, use only a neutral detergent cleaner with a soft damp cloth.

Do not spray with liquid or aerosol cleaners.

Do not expose this display to direct sunlight or heat. Hot air may cause damage to the cabinet and other parts.

Adequate ventilation must be maintained to ensure reliable and continued operation and to protect the display from overheating. Do not block ventilation slots and openings with objects or install the display in a place where ventilation may be hindered.

This display should be operated from the type of power source indicated on the AC/DC adapter.

Do not install this display near a motor or transformer where strong magnetism is generated. Images on the display will become distorted and the color irregular.

Do not allow metal pieces or objects of any kind fall into the display from ventilation holes.

Do not attempt to service this unit yourself. Removal of the display cover may expose you to dangerous voltage or other risks. Refer all servicing to qualified service personnel.

Unplug this product from the wall outlet and refer servicing to qualified service personnel in the event that:

1. Liquid is spilled into the product or the product is exposed to rain or water.
2. The product does not operate normally when the operating instructions are followed.
3. The product has been dropped or the cabinet has been damaged.
4. The product exhibits a distinct change in performance, indicating a need for service.
5. Power cord or plug is damaged or frayed.

General specifications for the LCD

The following items are neither defects nor failures.

- Response time, luminance and color gamut may be changed by ambient temperature.
- The LCD may be seemed luminance uniformity, flicker, vertical seam and/or small spot by display patterns.
- Optical characteristics (e.g. luminance, display uniformity, etc.) gradually is going to change depending on operating time, and especially low temperature, because the LCD has cold cathode fluorescent lamps.

.

.